

Nikon

DIGITAL CAMERA

COOLPIX® 885



Some cameras have all the fun

DIGITAL CAMERA

COOLPIX 885



Key features and benefits:

- High-resolution **3.2 effective Megapixel CCD**. Record images with a maximum 2048 x 1536 pixels for easy cropping and outstanding print quality.
- **High Quality 3x Optical Zoom-Nikkor lens** for clear sharp images plus 4x digital zoom for 12x total zoom.
- **Exclusive 256-segment Matrix Metering** helps you get great exposures in the most difficult lighting situations.
- **Fully Compatible** with optional Nikon Coolpix converter lenses and accessories.
- **Custom Setting Mode** lets you take control of the camera when you want to get serious.
- Includes **Nikon® Coolpix® Starter Memory Card**.

Battery charger and Lithium-ion rechargeable battery included



Compatible with optional Nikon Coolpix converter lenses, adapters and accessories.

3x Optical Zoom-Nikkor lens
(38mm – 114mm 35mm equivalent).

One-Touch Upload™

NikonNet

www.nikonnet.com

Actual size
(3.9"W x 3"H)
(only 7.9 oz.)



Quick Review
1.5" LCD Monitor with Quick Review lets you instantly confirm a shot you just took or review any of the other images stored on the CompactFlash™ Card.

Zoom Control

3x Optical Zoom
4x Digital Zoom
12x Total Zoom

Additional features:

Five Area AutoFocus



Noise Reduction Mode

Minimize digital artifacts in long exposures



White Balance Bracketing

Ensure proper color balance



12 Scene Modes:

The COOLPIX 885 features 12 specially programmed modes to automatically handle focus, exposure, white balance and other adjustments that help you take great pictures at the press of a button.



Portrait
Your subject comes out sharply focused with natural skin tones, against a soft, pleasant background.



Night Portrait
Using Slow Sync with Red-Eye Reduction in a scene with an illuminated background, your subject is naturally exposed.



Landscape
Emphasizing depth-of-field, this mode captures distant scenes sharply and clearly, for postcard-like landscape pictures.



Night Landscape
Use this mode to take in the true splendor of a nighttime scene using only ambient light.



Close Up
With precise manual focus area selection and appropriate coloration, this mode makes detailed subjects stand out from the background.



Back Light
The Speedlight fires to brighten subjects that are backlit and would come out dark if no flash was used.



Party/Indoor
In dim light, a slower shutter speed is automatically selected to bring out the background. In extremely low-light situations, the Slow Sync flash fires automatically.



Beach/Snow
When shooting a scene with snow or water in the background, the image is free of grayish tones that are caused by typical underexposure.



Sunset
Exposure is automatically controlled, enabling you to preserve the exquisite, natural beauty of a sunset.



Fireworks
With short shutter-release time lag, slow shutter speed, focus set at infinity, and other specific settings, you can capture fireworks in all their original beauty.



Copy
This mode is convenient when shooting characters printed on white material such as paper or white board. This is a great tool for application in business or at school.



Museum
Disables flash for indoor shooting in venues that do not allow flash.

Coolpix® 885

You don't need to be a serious photographer to take seriously good pictures. The Nikon Coolpix 885 digital camera makes it easy for anyone to capture and share the moment. Its 1.5" full color LCD monitor with Quick Review function lets you instantly see the picture you just took, or display any of the images stored on the CompactFlash™ memory Card. Extremely compact and lightweight at 7.9 ounces, the Coolpix 885 brings fun into focus wherever you go thanks to its high quality 3x Zoom-Nikkor lens and 3.2 effective Megapixel CCD. And taking great pictures has never been easier. Select from a dozen specially programmed scene modes that automatically control focus, exposure and other settings for optimum picture quality in almost any shooting situation. The camera is easy to operate and even easier to connect directly to your computer without the need for additional components. Downloading pictures to your computer and/or the web is a breeze using the Coolpix 885's Transfer Button. The Nikon Coolpix 885 lets you explore your creativity. Seriously.

Digital Camera Specifications:

CCD:	Total number of pixels 3.37 million (3.21 million pixels effective)
Lens:	3x Zoom-Nikkor (4x Digital Zoom) f=8-24mm [35mm camera format equivalent to 38-114mm]
Viewfinder:	Real image optical zoom viewfinder
LCD monitor:	1.5-in. low temp polysilicon TFT LCD
Storage media:	CompactFlash™ card
Built-in Speedlight:	Sensor flash system/Guide number 8/27 (at ISO 100,m/ft.)
Interface:	USB 1.1 interface Video output (NTSC/PAL selectable)
Power requirements:	(1) 6V 2CR5/DL245 Lithium Battery (included), Rechargeable Li-ion battery EN-EL1 (optional), EH-21AC Adapter/Charger
Dimensions (WxDxH):	3.78 x 3.717 x 2.047 in. [95 x 69 x 52mm]
Weight (without battery):	approx. 7.9 oz.
System Requirements:	USB: Windows® 98/98SE pre-installed model, Windows® 2000 or later, MMX® Pentium® or later Mac® OS 8.6 or later (Only built-in USB ports are supported), iMac®, iBook®, Power Macintosh® G3 (Blue & White) or Power Mac® G4 or later, Power Book G3 (with USB built-in) or later
Accessories Included:	Lens cap, Strap, Video cable, Nikon® Coolpix® Starter Memory Card, EN-EL1 Rechargeable Li-ion Battery, MH-51 Battery Charger, USB cable, NikonView Ver.5 CD-ROM, Open Me First Envelope, Manual
Optional Accessories:	Various size CompactFlash™ cards, PC card adapter, Wideangle converter, Telephoto converters, Fisheye converter, Slide Copying Adapter, Step-down ring adapter UR-E4 (Required to use converter lenses and Slide Copying Adapter), Remote Cord, Case
Bundled Software:	NikonView 5, ArcSoft® PhotoImpression™ 2000, ArcSoft VideoImpression™ 2000, ArcSoft Panorama Maker™, ArcSoft PhotoBase for™ Palm OS®
Product number:	25505

All products indicated by trademark symbols are trademarked and/or registered by their respective companies. Specifications and equipment are subject to change without any notice or obligation on the part of the manufacturer. 02/02

©2002 NIKON INC.

Optional Coolpix Accessories:



UR-E4
Converter Adapter



FC-E8*
Fisheye Converter Lens



WC-E63*
Wide-Angle Converter Lens



WC-E68**
Wide-Angle Converter Lens



TC-E2*
2x Tele Converter Lens



TC-E3ED*
3x Tele Converter Lens



UR-E7
Converter Adapter



ES-E28*
Slide/Film Copying Adapter



MC-EU1
Remote Cord



EH-52
AC Adapter



885/880 Case

* Requires Converter Adapter UR-E4
** Requires Converter Adapter UR-E7

Additional accessories can be found at
www.nikoncoolpix.com
on the Coolpix 885 page

Nikon

1300 Walt Whitman Road, Melville, NY 11747

www.nikonusa.com / 1-800-Nikon-UX

LEXAR
Media™